

PhoXi Firmware Updater

PhoXi Firmware Updater is a standalone application that updates firmware on PhoXi 3D Scanners using mechanism independent of PhoXi Control. The application is available starting from firmware version 1.2.26.

1. Download the PhoXi Firmware Updater application:

Windows:

www.photoneo.com/dl/updater-win

Ubuntu:

www.photoneo.com/dl/updater-lin

2. Depending on your operating system, run the application:
 - a. **Windows:** double click the application
 - b. **Ubuntu:** run the script from terminal using ID of the scanner or its IP address as an argument

```
phoxi-fw-update-<version> 2019-10-139-LC3
```

3. Type the ID or IP address of the device you wish to update into the console after the prompt.
 - a. If you are using the application on your Windows computer for a first time, you may need to allow it access through your firewall.
4. Firmware update takes around one minute to complete. The device reboots once the update is done. Watch [update gif](#).



```
C:\Users\Hana Vrbovska\Desktop\updater5\phoxi-fw-update-1.2.26-5-b95a0e2a.exe
Update firmware on Photoneo 3D scanners.
Please enter a serial number, ip address or hostname of the device to patch:
> 2019-10-139-LC3
Update firmware on Photoneo 3D scanners.

Applying to 2019-10-139-LC3
Looking for 2019-10-139-LC3
-
```


Update to Earlier Firmware Version

Update to earlier firmware versions (before 1.2.26) was performed via PhoXi Control

- Read the full instructions at www.photoneo.com/kb/fw-update1.2-old

Assistance

If you require assistance, please contact support@photoneo.com. Attach the `log.txt` file created by the application.